



Pipework in blue is the 90mm stormwater pipe from your guttering. The orange pipework is the “First Flush Diverter” that we recommend with all tanks. The red pipe is the overflow from the tank and the purple pipe is the 90mm stormwater pipe that takes overflow water back into the stormwater discharge in the ground. The dotted line pipework is the piece of downpipe that you will need to remove and the grey piece at the bottom is the stormwater discharge.

**Irrigation Warehouse Group Pty Ltd**  
**Ph 02 6732 6333 Fax 02 6732 6311**  
**Connections for Polyethylene Tanks**  
 Drawn: RDE Checked: RI Date: 02/02/05